

Technical Bulletin: 2019.02

PreFixx® Protective Finish Chemical & Disinfectant Resistance

Subject:

Guidance for Disinfection

Summary:

OMNOVA Solutions manufactures a variety of performance fabrics sold under brands such as **Boltaflex®**, **BoltaSoft®**, **Nautolex®** and **PreVail®**. Many of the performance fabrics feature a **PreFixx®** protective finish, which resists damage from disinfectants.

Cleaning After Disinfection:

The following cleaners should be used with a soft cloth or damp sponge to remove chemical residue.

- Formula 409® All-Purpose spray cleaner
- Hand dishwashing soap and water

After cleaning, rinse area with clean water, then dry with a clean, lint-free cloth. Failure to remove chemical residue will cause discoloration of the coated fabric surface to manifest earlier in the life cycle of the product.

Disinfectant Use:

In laboratory testing, upholstery protected with **PreFixx** finish was treated with the following disinfectants with little to no discoloration or damage to the upholstery. This testing may not reflect actual results in the field.

Please see reverse side for full list of recommended disinfectants.



t 877-963-5537
www.woeller.com

CONTINUED ON NEXT PAGE...

Recommended Disinfectants**

- Agar™ Powerquat
- Asepticare™
- Asepticare™ TB-II
- AVISTAT-D™ Ready To Use Spray Disinfectant and Cleaner
- Biotrol BirexSE®
- Bleach 1:5 (20% bleach)
- Bleach 1:9 (10% bleach)
- Bleach-Rite® Disinfecting Spray
- CaviCide™
- CaviCide1™
- CaviCide™ AF
- Clorox® Broad Spectrum Quaternary Disinfectant Cleaner
- Clorox® Healthcare Bleach Germicidal Cleaner
- Clorox® Healthcare Bleach Germicidal Wipes
- Clorox® Healthcare EZ-KILL® Wipes
- Clorox® Healthcare VersaSure® Cleaner Disinfection Wipes
- Clorox® Hydrogen Peroxide Cleaner Disinfectant Spray
- Clorox® Hydrogen Peroxide Cleaner Disinfectant Wipes
- Diversey™ Accel® INTERvention® Wipes
- Diversey™ Avert® Sporicidal Disinfectant Cleaner
- ERC Performance Wipes
- Isopropyl Alcohol 70%
- McKesson Disposable Germicidal Surface Wipes
- McKesson Pro-Tech RTU Disinfectant Cleaner
- OPTIM® 1 Wipes
- OPTIM® 33TB
- Oxivir® 1 RTU
- Oxivir® Five 16
- Oxivir® TB
- OxyCide™ Daily Disinfectant Cleaner
- PDI Sani-Cloth® AF3 Germicidal Disposable Wipes
- PDI Sani-Cloth® HB
- PDI Sani-Cloth® Plus
- PDI Sani-Cloth® Prime Germicidal Disposable Wipe
- PDI Super Sani-Cloth®
- PDI Super Sani-Cloth® Bleach Germicidal Disposable Wipes
- Precise QTB Spray
- PROCHEM® Oxy Plus
- Purell® Healthcare Surface Disinfectant
- Purell® Multi-Surface Disinfectant
- Sani Professional® Cleaning + Degreasing Multi-Surface Wipes
- Sani Professional® Multi-Surface Cleaning Wipes
- Sani Professional® No-Rinse Sanitizing Multi-Surface Wipes
- SaniZide® Plus
- STERI-7 XTRA CONCENTRATE (recommended dilution ratio 1:10)
- STERI-7 XTRA WIPES
- Vert-2-Go ED
- Virox AHP 5
- Virox PREempt™ RTU
- Virex® II 256
- Virex® Plus One-Step Disinfectant Cleaner & Deodorant
- Wayne® Concept 256N
- Wex-Cide 128

* All disinfectants and cleaning agents contain chemicals that degrade coated fabric upholstery to some extent. To promote a long product life, it is recommended that the PreFixx cleaning and maintenance protocol be employed regularly.

**Inclusion in this document does not imply "fit for use." Customers should first determine if products are appropriate for use on their surfaces.



t 877-963-5537
www.woeller.com